# RS232 Relay Board 8-Channel 5-Amp ProXR Lite
R85PL_ZRS

RS232 Relay Board

The R85PL_ZRS RS232 Relay Board will connect to any computer or device through a DB-9 or direct wire connection that has the ability to send numerical commands. The board will mount to any existing COM port for computer connections and connect to other devices through an RS-232 connection. Add relay control to Crestron, AMX or any system that has a DB9 interface where you need to control a relay!

R85PL_ZRS The Ideal Choice

The R85PL_ZRS RS232 Relay Board allows you to program in almost any language and has the ProXR Command Set, the industry leading command set for controlling the relay and reading the inputs on the board. Commands can be as simple as turning on/off each relay individually and as complex as adding delays and other features to the command such as flashers, grouping relays, and controlling banks of relays at once.

OVERVIEW

RS232 Relay Board at a Glance

- 8 5-Amp Relays Installed
  - Single Pole Double Throw (SPDT) Relay
  - Temperature Rating -40° C to 85° C
  - Not-Expandable
- RS232 Interface w/Choice of RS232 connector
  - Onboard DB9 Connector:
  - Screw Terminal Connector
  - Off the Board DB9 Connector
  - Connects to Any Available COM Port
- Connects to Third Party Devices
  - Creston, AMX & More!
- Industry Leading Command Set
  - Send Specific Commands to Trigger Relays
  - Trigger Any or All Relays
  - Program in Almost any Language
  - Read 0 to 5 Volt Sensors

800-960-4287
sales@relaypros.com
www.relaypros.com